






<p>2 Post Center Mount Overview</p>	
<p>Front View</p>	
<p>Inner Rail Overview</p>	
<p>Outer Rail Interior View</p>	
<p>Outer Rail Exterior View</p>	

Tolerance ± 0.01      ALL DIMENSIONS ARE IN INCHES.      Printed on 3/18/2022      Sheet 1 of 2


## 2 Post Center Mount Rack Fit Guide

**Note:**

A **positive** value indicates the answer to the corresponding question is **Yes**.

A **negative** value indicates the answer to the corresponding question is **No**.

<u>Question</u>	<u>Formula</u>
Will the <u>outer rail</u> extend past the <u>rack</u> ?	$13.65 - D$
Will the <u>inner rail</u> extend past the <u>outer rail</u> ?	$B - 0.79$
Will the <u>inner rail</u> extend past the <u>server</u> ?	$26.09 + B - L$
Will the <u>server</u> extend past the <u>outer rail</u> ?	$L - 26.88$
Will the <u>rear bracket</u> extend past the <u>outer rail</u> ?	$D - 3.10$
<u>Variables</u>	<b>B</b> = Server Ear to First Button <b>D</b> = Rack Mounting Depth <b>L</b> = Server Length



Tolerance ± 0.01

ALL DIMENSIONS ARE IN INCHES.

Printed on 3/18/2022

Sheet 2 of 2

**RackSolutions®**

Outline Drawing  
racksolutions.com

Dwg No & Rev  
122-2413-921