

Tolerance ± 0.01 ALL DIMENSIONS ARE IN INCHES. Printed on 3/18/2022 Sheet 1 of 2


4 Post Mount Rack Fit Guide

Note:

A **positive** value indicates the answer to the corresponding question is **Yes**.

A **negative** value indicates the answer to the corresponding question is **No**.

Question	Formula
Will the <u>outer rail</u> extend past the <u>rack</u> ?	$26.60 + T - D$
Will the <u>inner rail</u> extend past the <u>rack</u> ?	$25.84 + B - D$
Will the <u>inner rail</u> extend past the <u>server</u> ?	$26.09 + B - L$
Will the <u>server</u> extend past the <u>rack</u> ?	$L - D - 0.25$
<u>Variables</u>	B = Server Ear to First Button D = Rack Mounting Depth L = Server Length T = Rack Upright Thickness



Tolerance ± 0.01

ALL DIMENSIONS ARE IN INCHES.

Printed on 3/18/2022

Sheet 2 of 2

RackSolutions®

Outline Drawing
racksolutions.com

Dwg No & Rev
122-2413-920