






<p>2 Post Center Mount Overview</p>	
<p>Front View</p>	
<p>Inner Rail Overview</p>	
<p>Outer Rail Interior View</p>	
<p>Outer Rail Exterior View</p>	

Tolerance ± 0.01

ALL DIMENSIONS ARE IN INCHES.

Printed on 9/16/2021

Sheet 1 of 2

RackSolutions®

Outline Drawing
racksolutions.com

Dwg No & Rev
122-2579-921

2 Post Center Mount Rack Fit Guide

Note:

A **positive** value indicates the answer to the corresponding question is **Yes**.

A **negative** value indicates the answer to the corresponding question is **No**.

<u>Question</u>	<u>Formula</u>
Will the <u>outer rail</u> extend past the <u>rack</u> ?	$13.65 - D$
Will the <u>inner rail</u> extend past the <u>outer rail</u> ?	$B - 0.54$
Will the <u>inner rail</u> extend past the <u>server</u> ?	$26.34 + B - L$
Will the <u>server</u> extend past the <u>outer rail</u> ?	$L - 26.88$
Will the <u>rear bracket</u> extend past the <u>outer rail</u> ?	$D - 3.15$
<u>Variables</u>	B = Server Ear to First Button D = Mounting Depth (Post Width) L = Server Length

