




4 Post Mount
Overview




Front View




Inner Rail
Overview



Outer Rail
Interior View



Outer Rail
Exterior View



Tolerance ± 0.01

ALL DIMENSIONS ARE IN INCHES.

Printed on 5/1/2023

Sheet 1 of 2

RackSolutions®

Outline Drawing
racksolutions.com

Dwg No & Rev





122-7650-920

4 Post Mount Rack Fit Guide

Note:

A **positive** value indicates the answer to the corresponding question is **Yes**.
 A **negative** value indicates the answer to the corresponding question is **No**.

Question	Formula
Will the <u>outer rail</u> extend past the <u>rack</u> ?	$24.10 + T - D$
Will the <u>inner rail</u> extend past the <u>rack</u> ?	$22.52 + B - D$
Will the <u>inner rail</u> extend past the <u>server</u> ?	$22.76 + B - L$
Will the <u>server</u> extend past the <u>rack</u> ?	$L - D - 0.24$
Variables	B = Server Ear to First Button D = Rack Mounting Depth L = Server Length T = Rack Upright Thickness



Outer Rail

Tolerance ± 0.01

ALL DIMENSIONS ARE IN INCHES.

Printed on 5/1/2023

Sheet 2 of 2

RackSolutions®

Outline Drawing
racksolutions.com

Dwg No & Rev

122-7650-920