



*Boldly Creative*



*Expert Customer Service*




*Focus On Quality*



*Ships Same Day*

# Combination Lock Operation Instructions



Operation Instructions

Kit P/N: 106-4075

# Opening Handle

---


## With the key

- Insert the key into the lock.
- Turn the key 180 degrees counter clockwise. Lift the handle and turn.
- To re-lock, turn the key 180 degrees clockwise.



## With combination lock


- Dial in correct combination, (factory set at "000").
- Turn wing knob 180 degrees counter clockwise until the Arrow Indicator points up towards the Unlock Symbol. Lift the handle and turn.



# Changing the Combination

---


**Step 1** Fix Position: The keylock must be in the locked position with the Arrow Indicator pointed down towards the Lock Symbol.



**Step 2** Enter Current Combination: Input the existing combination with the turn dials (factory set at "000").


## Changing the Combination

**Step 3** Turn Wing Knob: Turn wing knob 180 degrees + 15 degrees counter clockwise.




**Step 4** Enter New Combination: Use dials to enter new combination.

**Step 5** Set Combination: Turn wing knob 15 degrees clockwise, the new combination is now set.



**Step 6** Lock and Reset: Turn wing knob 180 degrees clockwise to lock, then scramble the combination.





**We promise you're going to have a great experience.**



*Boldly Creative*



*Expert Customer Service*



*Focus On Quality*



*Ships Same Day*

Warranty Statement

Innovation First, Inc. warrants our products against defects in material and workmanship for a period of one (1) year from the date of purchase. Innovation First, Inc. liability shall be limited to repairing or replacing, at our option, any defective product.

**4075**