




Stand Brackets for Dell Server R7



Installation Instructions
P/N: BRK-R7-STAND-001


Kit Contents

Kit Contents

(2) Base Brackets

Installation Instructions

Step 1. Base Brackets Attachment: The Dell Server can be installed in two configurations. Decide which configuration and remove the two outer Dell Shoulder Nuts from the side that the Base Brackets will be attached. Install Base Brackets and Dell Shoulder Nuts as shown below. Ensure that the Base Bracket Flange is as close as possible to the Dell Server Bottom and then secure the Dell Shoulder Nut.





Boldly Creative



Expert Customer Service



Focus On Quality



Ships Same Day

Warranty Statement

Innovation First, Inc. warrants our products against defects in material and workmanship for a period of one (1) year from the date of purchase. Innovation First, Inc. liability shall be limited to repairing or replacing, at our option, any defective product.