



Boldly Creative



Expert Customer Service




Focus On Quality



Ships Same Day

Patent(s) Pending

Sliding Quick Rail Kit for Dell 2950 Server



Installation Instructions
Kit P/N: QUICKRAIL-2950

Kit Contents

Kit Contents

- (1) Cable Management Arm Assembly
- (2) Rail Assembly

Rail Hardware:


- (7) 10-32 x .375 Truss Head Screws
- (2) 8-32 x .188 Phil Pan Head
- (2) 8-32 x .375 Phil Pan Head

Cable Arm Brackets:


- (1) Long CMA Bracket

Installation Instructions

Step 1. Rear Brackets: The rear brackets are pre-set for the most common "Mounting Depth Range" which is 28.25"-29.5". If this is not correct for your rack, you can remove the nuts and reposition the brackets. Which can then cover a "Mounting Depth Range" from 25.25" to 31".




Step 2. Rail Attachment: Slide the innertrack of the rail completely out of the outer rail. You do this by pulling up on the safety latch, then out on the rail. Then remove the front Dell shoulder nut, and slide the rail onto the box. Then reattach the Dell shoulder nut which will lock the rail in place. Repeat for other side.




Installation Instructions

Step 3. Mount Outer Rail Assemblies: Mount both rails in the Rack as shown below. You can mount Cable Management Arm on whichever side you choose.




Step 4. Mount Box: Fully extend the rails first into their locked position, then slide the chassis in carefully using two people.





Installation Instructions

Step 5. Attach CMA Bracket: Attach the CMA Bracket to the inner shim, using the specified hardware.



Warranty Statement

Innovation First, Inc. warrants our products against defects in material and workmanship for a period of one (1) year from the date of purchase. Innovation First, Inc. liability shall be limited to repairing or replacing, at our option, any defective product.