

Boldly Creative


Expert Customer Service


Focus On Quality

Ships Same Day

Patent(s) Pending

1U Adapter Bracket Set





Installation Instructions Kit P/N: 1UKIT-106

RackSolutions.com

Kit Contents

Brackets:

- (2) 1U 059 – 2 Bend Bracket
- (2) 1U 100 – 2 Bend Bracket 1U 290 – 2 Bend Bracket
- (2) (2) 1U 200 – 4 Bend Bracket

1U 350 - 4 Bend Bracket


Rack Mount Hardware Kit:

- (12) 12-24 x 3/8" Screws
- 10-32 x 3/8" Screws (8) (8) 12-24 Square Nuts
- (4) 12-24 Cage Nuts


- (2) 1U 270 - 4 Bend Bracket
- (2)

Bracket Installation Instructions

Step 1. Determine your rack type: There are slight differences in the installation of this kit into a "4Post Cabinet" rack and a "Double 2Post" rack. The instructions that follow will refer to the rack type.



Step 2. Measure the "Mounting-Depth" for your rack from the front of the "Front-Mounting-Surface" to the back of the "Back-Mounting-Surface" (see the figure below).



Page 2

RackSolutions.com

Bracket Installation Instructions (continued)

Step 3. Locate the best fit for your "Mounting-Depth" in the table below: This chart determines which adapter brackets you will need and where they should be mounted. The kit includes two each of 6 different brackets, identified as 059, 100, 290, 200, 270, and 350.

Bracket 059 = 0.59" wide with 2-bends Bracket 100 = 1.00" wide with 2-bends Bracket 290 = 2.90" wide with 2-bends Bracket 200 = 2.00" wide with 4-bends Bracket 270 = 2.70" wide with 4-bends Bracket 350 = 3.50" wide with 4-bends

Width code is stamped on most brackets.

Mounting Depth (in.)			Front-Adapter Type	Rear-Adapter Type
22 5/8	to	23 1/2	059	270+350 (ref App. B)
23 1/2	to	24 1/4	059	200+350 (ref App. B)
24 1/4	to	25 1/8	059	200+270 (ref App. B)
25 1/8	to	25 3/8	290	270+350 (ref App. B)
25 3/8	to	26 1/4	059	350
27	to	27 3/4	059	200
27 3/4	to	28 1/2	200	270
28 1/2	to	29 1/4	290	270
29 1/4	to	30	270	200

4Post Rack Cabinets Only

Double 2Posts Only


Rack-Depth (in.)			Front-Adapter Type	Rear-AdapterType
23 7/16	to	24 3/8	059	200+350 (ref App. B)
24 3/8	to	25 1/4	059	200+270 (ref App. B)
25 7/16	to	26 3/8	059	350
26 3/8	to	27	059	270
27	to	28	059	200
28 1/4	to	29 1/8	059 (ref Appendix A)	350
29 1/8	to	30	059 (ref Appendix A)	270

These tables summarize the typical brackets for a given Mounting Depth. Not all combinations are shown.

Experimentation is recommended if difficulties arise.

Bracket Installation Instructions (continued)

Step 4. <u>Adapter Location on Rail:</u> All adapters in this kit occupy "1U" of rack space. This "1U" of space covers three holes and 1.75".




Page 4

RackSolutions.com

Bracket Installation Instructions (continued)

Step 5. Install the brackets determined by Step 3.



Refer to Slide Installation Instructions on Page 6

Assembly Notes:

- 1. Repeat installation shown for both sides of rack.
- 2. Double rear spacers are required for Mounting-Depths of 22 5/8" to 25 3/8". Refer to Appendix B.
- 3. Screws shown are for racks with threaded holes. If your rack has non-threaded holes, install the screw from the front of the rack, and use a nut on the inside against the adapter bracket.
- 4. If installation difficulties arise, see the alternate attachment method shown in Appendix C.

Page 5

RackSolutions.com


Slide Installation Instructions

Installing the Dell Slides and Cable Management Arm per Dell instructions. Installation photos can be viewed at www.racksolutions.com.

Appendix A - Double 2Post Front-Adapters

This step is only necessary for Double 2Post racks from 28 1/4" to 30"

Install the adapter on the back (rear) side of the front C-Channel post as shown below. Attach using (2) 12-24 screws. Repeat for both front brackets.



Page 6


RackSolutions.com

Appendix B - Dual Rear-Adapters

This step is only necessary for Mounting Depths from 22 5/8" to 25 3/8"

Attach the two brackets (indicated in step 2) together as shown below using (2) Cage Nuts and (2) 12-24 screws. Be sure the longer bracket is at the rear.


Install the bracket pairs to the Rear Rack Rail as shown below using (2) 12-24 screws. Repeat for the opposite side.



Appendix C - Alternate Front-Adapter Installation

Due to the variety of 19" rack designs, the standard installation may not work.

The figure below shows installation of the front spacer with the "U-Shape" pointing outward. Install using (2) 12-24 screws. Repeat for the opposite side. If rack holes are not threaded, install screws through the rack, then through the adapter, and into a nut (supplied).



Page 7

RackSolutions.com

We promise you're going to have a great experience.











Expert Customer Service

Warranty Statement

If we can't mount it , no one can.

Innovation First, Inc. warrants our products against defects in material and workmanship for a period of one (1) year from the date of purchase. Innovation First, Inc. liability shall be limited to

repairing or replacing, at our option, any defective product.