



*Boldly Creative*



*Expert Customer Service*




*Focus On Quality*



*Ships Same Day*

## Sliding Rail Kit for Dell Servers



### Installation Instructions

Kit P/N: 2URAIL-2650

2URAIL-2850

2URAIL-2950

# Kit Contents

## Kit Contents


- (1) Cable Management Arm Assembly
- (2) Inner Rail/Shim Assemblies
- (2) Outer Rail/Rack Bracket Assemblies
- (1) Long CMA Bracket

## Cable Arm Hardware:

- (2) Rear Alignment Brick
- (2) Front Alignment Brick
- (2) 8-32 x .250 Phil Pan Head
- (2) 8-32 x .188 Phil Pan Head



Rear Alignment Brick




Front Alignment Brick

## Rail Hardware:


- (5) 8-32 Keps Nuts
- (21) 8-32 x .375 Truss Head Screws

# Installation Instructions

**Step 1. Attach Rear Brackets:** Attach the rear brackets to the outer rail assemblies, using included 8-32 x .375 truss head screws and keps nuts. Make sure you attach them at the desired "Mounting Depth".




**Step 2. Rail Attachment:** Slide the innertrack of the rail completely out of the outer rail. You do this by pulling forward on the Plastic Safety Latch, then out on the rail. Remove the front Dell Shoulder Nut, and slide the rail onto the box. Reattach the Dell Shoulder Nut which will lock the rail in place. Repeat for the other side.




# Installation Instructions

**Step 3. Mount Outer Rail Assemblies:** Mount both rails in the Rack as shown below, pay attention to which alignment brick you use as they are not the same.





**Step 4a. For Mounting Depth Greater Than 28":** Use the short CMA bracket attached to the rear of the rack (comes attached on CMA arm).

**Step 4b. For Mounting Depth Less Than 28":** Use the long CMA bracket attached to either the Rack or the end of the Rail that is sticking out depending on your configuration.



Short CMA Bracket  
Attached to Rack using  
Rack mount screws



CMA Bracket  
Attached to  
Rack using Rack  
mount screws

**Step 5. Attach CMA Arm Assembly:** Attach CMA arm assembly to the bracket mounted to your rack if it isn't already.



*Boldly Creative*



*Expert Customer Service*




*Focus On Quality*




*Ships Same Day*

## Installation Instructions

**Step 6.** Mount Box: Using two people carefully slide the box into the rails in the rack.



**Step 7.** Attach CMA: Attach the CMA Bracket to the inner shim, using the specified hardware.



### Warranty Statement

Innovation First, Inc. warrants our products against defects in material and workmanship for a period of one (1) year from the date of purchase. Innovation First, Inc. liability shall be limited to repairing or replacing, at our option, any defective product.

**559 802 803**