




2U Cobra 135-A Rail for Dell



Installation Instructions

Kit P/N: 122-9089

Kit Contents

Kit Contents:

- (2) Outer Rail (Left & Right)
- (2) Inner Rail (Left & Right)
- (2) Rear Bracket

Mounting Hardware:


- (22) 8-32 x .500 Pan Head Screw
- (2) Latch Plate (Left & Right)
- (2) Mounting Plate

Rear Bracket Hardware:


- (9) 8-32 x .312 Flat Head Screw
- (9) 8-32 Keps Nut

4Post Installation Instructions

- Step 1 **Rail Attachment:** Attach the Inner Rail to the chassis by aligning the Shoulder Lugs with the keyholes in the Inner Rail and slide until the retaining clip has secured the Inner Rail to the server. Repeat for the other side.




- Step 2a **Attach Rear Brackets:** Attach the Rear Brackets to each Fixed Rail using the provided (4) 8-32 Flat Head Screws and (4) 8-32 Nuts. Do not fully tighten the screws until after Step 2b. Always install the (4) screws and nuts as widely spaced as possible. Repeat for the other side (right side shown).




- Step 2b **Tighten Rear Brackets:** Hold the assembled rail up to the rack; adjust the rear bracket to ensure that the rail is pushed up against the inside of the front and rear upright. Once the rail is at the correct depth, tighten the (4) screws and nuts. Repeat for the other side.

4Post Installation Instructions

Step 3 Attach the Rails to the Rack: Attach the Front and Rear of the rails to the 4Post rack as shown below using supplied 8-32 Pan Head Screws on each side. Repeat for the other side (Right side shown).



Step 4 Install the Equipment: Slide the equipment all the way into the Outer Rail Slides; ensuring the Inner Rails slide into the Inner Rail Catch Brackets.





Boldly Creative



Expert Customer Service



Focus On Quality



Ships Same Day

You're going to ♥ working with us Global company - small town service


Custom Engineering

Our top notch (in-house) mechanical and electrical engineers are available to solve your toughest custom design challenges.




On-Site Manufacturing

Our manufacturing facility is on-site at our Texas headquarters. If we send them a drawing in the morning, we can have parts ready to ship-out that evening.



Online, in stock, and always growing

Our distribution centers are packed. Check our website to see if your solution is ready and waiting. Our availability is shown in real time.



In-House Advantage

Customer support, engineering, and logistics are standing by to get you whatever answers you need. Even if that means walking down and asking the guy who made it for you.

Warranty Statement

Innovation First, Inc. warrants our products against defects in material and workmanship for a period of one (1) year from the date of purchase. Innovation First, Inc. liability shall be limited to repairing or replacing, at our option, any defective product.

9089